



F16. Z

INITIALIZE MEMORY INTERFACE
CONTROL LOSIL

WAIT FOR CLOCKS TO

SYNCHRONIZE

JIO

SET A CURRENT CONTROL

RECISTER

(E.G., TO MIOPOINT)

PERFORM MEMORY CORE

INITIALIZATION

CPERATIONS

(E.G., PRECHARGE &

REFRESH SEQUENCE)

330

F16.3